



A251 Clamp Adapter

Using the A251 AC Clamp-On Adapter with Digital Multimeters



The A251 AC Clamp-On Adapter has an output of 1mV / 1A. It must be connected to the V and COM jacks not the A and COM jacks.

1. Connect the output jack of the Clamp-On Adapter to the **V** and **COM** jacks of the DMM.
2. Set the Digital Multimeter to the **AC Volt** range to read **AC Amperes**.
3. Turn the Clamp-On Adapter on.
4. Clamp the Adapter around a **single** current carrying wire. The adapter **cannot** be clamped around more than one wire, for example a power cord.
5. Read the amperage on the multimeter. **Remember 1 millivolt equals 1 Amp.**